- (6) M Identify uncertainty in measurements
- (7) S Calculate percentage uncertainty
- (8) C Combine absolute and percentage uncertainty



Lesson 4. Uncertainty 2

STARTER:

Measure the diameter of the marble with a) micrometer and a b) caliper.

Write the value and the percentage uncertainly of

Kilo 10³

Compare the % uncertainty of both and suggest reason for the difference


Mega 10 Giga


Explain the difficulties you encoutered when measuring the marble.



15.525 mm = 0.003%

) 15.75 mm ± 3%







Percentage uncertainty - A measure of accuracy



(absolute) × 100% percentage uncertainty = -

Example measuring cylinder (from starter) -Find the % uncertainty of the 2 values in the starter. Comment on the answer....

> 1.5% 16.5 ml.

(give students one high volume one low volume)



- (7) S Calculate percentage uncertainty
- (8) C Combine absolute and percentage uncertainty



Combining uncertainty



In a calculation, if several of the quantities have uncertainties then these will all contribute to the uncertainty in the answer. The following rules will help you calculate the uncertainty in your final answers.

- 1. When quantities are added, the uncertainty is the sum of the *absolute* uncertainties.
- When quantities are subtracted, the uncertainty is also the sum of the absolute uncertainties.

Example

3.



John 186cm +- 🔾 [📣 Alice 175cm +- 0.1

If Alice stands on Johns head, what is the combined height?

361±0.2

When quantities are multiplied, the total percentage uncertainty is the sum of the percentage uncertainties.

when quantities are divided, the *total percentage* uncertainty is also the sum of the percentage uncertainties.

Example

Find the area, including the absolute uncertainty



When a quantity is raised to the power n, the total percentage uncertainty is n multiplied by the *percentage* uncertainty – for example, for a quantity x^2 , total percentage uncertainty = 2 percentage uncertainty in x.

Example



Fred's pool is a perfect cube of length (L) = 8m + -0.05m

